


Operating Instructions

PS-AMS1x PSL Model 4



Version 2023/08/02

©2023 PS Automation GmbH

Subject to changes without notice!

Contents

Contents.....	2
1. Symbols and safety	3
2. Usage as per specification	4
3. Storage	4
4. Operating conditions	4
4.1 Installation position	5
5. Function	5
6. Manual operation	6
7. Valve mounting	7
7.1 PS-AMS PSL202-214	7
7.2 PS-AMS PSL320-325	9
8. Removing the cover	10
9.2 Wiring diagram	12
9.3 Mains supply	13
9.3.1 Mains supply 1-phase AC/DC.....	13
9.3.2 Mains supply 3-phase AC (optional)	13
9.3.3 Mains supply PS-AMS PSL320/325 with integrated local control PSC.2	14
9.4 Interfaces	15
9.4.1 Communication interface	15
9.4.2 Input terminals	15
9.4.2.1 Galvanically isolated set-value.....	15
9.4.2.2 Sensor feedback for process controller (optional)	16
9.4.2.3 Galvanically isolated binary input.....	16
9.4.2.4 Fail-safe port for binary input (optional)	16
9.4.3 Output terminals	16
9.4.3.1 Active position feedback.....	16
9.4.3.2 Additional position switches (optional)	17
9.4.3.3 Voltage feed to process sensor (optional).....	17
9.4.3.4 Fault indicating relay.....	17
9.4.3.5 Fieldbus interface (optional).....	17
9.5 Accessories.....	17
9.5.1 Heating resistor (optional).....	17
9.5.2 Adjusting additional position switches (optional)	18
10. Status display / Commissioning elements	19
11. Closing the cover.....	19
12. Operation.....	20
12.1 Cut-off in end positions	20
12.1.1 Cut-off by force/torque	20
12.1.2 Cut-off by position automatically	20
12.1.3 Cut-off by position	20
13. Commissioning.....	20
13.1 Automatic commissioning	21
13.2 Manual commissioning.....	21
14. Status messages.....	22
14.1 Fault indicator relay	22
14.2 Tracing faults.....	22
15. Maintenance	22
16. Disposal.....	22
17. Safety on transportation.....	22
18. Accessoires.....	23
19. Tracing faults.....	24
20. EC Declaration of Conformity	26
21. CA Declaration of Conformity	27

1. Symbols and safety

General dangers of non-compliance with safety regulations

PS-AMS PSL actuators are built at state-of the art technology and are safe to operate. Despite of this, the actuators may be hazardous if operated by personnel that has not been sufficiently trained or at least instructed, and if the actuators are handled improperly, or not used as per specification.

This may

- cause danger to life and limb of the user or a third party,
- damage the actuator and other property belonging to the owner,
- reduce safety and function of the actuator.

To prevent such problems, please ensure that these operating instructions and the chapter on "Safety" in particular have been read and understood by all personnel involved in the installation, commissioning, operation, maintenance and repair of the actuators.

Basic safety notes

- The actuators may only be operated by skilled and authorized operating personnel.
- Make sure to follow all security advices mentioned in these operating instructions, any national rules for accident prevention, as well as the owner's instructions for work, operation and safety.
- The isolating procedures specified in these operating instructions must be followed for all work pertaining to the installation, commissioning, operation, change of operating conditions and modes, maintenance, inspection, repair and installation of accessories.
- Before opening the actuator cover, ensure that main supply is isolated and prevented from unintended re-connection.
- Areas that can be under voltage have to be isolated before working on them.
- Ensure that the actuators are always operated in faultless condition. Any damage or faults, and changes in the operational characteristics that may affect safety, must be reported at once.

Danger signs

The following danger signs are used in these operating instructions:



Caution! There is a general risk of damage related to health and/or properties.



Danger! Electrical voltages are present that may lead to death. Life threatening risks may occur due to electrical voltages!



Danger! This sign warns of hazards posing a risk to health. Ignoring these instructions can lead to injuries.



Attention! Observe precautions for handling. Electrostatic sensitive devices.

Other notes



- The motor surface temperature may rise when maintaining, inspecting and repairing the actuator immediately after the operation. There is a danger of burning the skin!
- Always consult the relevant operating instructions when mounting PS accessories or operating the actuator with PS accessories.
- Connections for signal in- and output are double isolated from circuits that can be under dangerous voltage.

2. Usage as per specification

- PS-AMS PSL linear actuators are exclusively designed to be used as electric valve actuators. They are meant to be mounted on valves in order to run their motors.
- Any other use is considered to be non-compliant and the manufacturer cannot be held liable for any damage resulting from it.
- The actuators can only be used within the limits laid out in the data sheets, catalogues and other documents. Otherwise, the manufacturer cannot be held liable for any resulting damage.
- Usage as per specification includes the observance of the operating, service and maintenance conditions laid down by the manufacturer.
- Not to be regarded as usage as per specification are mounting and adjusting the actuator as well as servicing. Special precautions have to be taken while doing this!
- The actuators may only be used, serviced and repaired by personnel that is familiar with them and informed about potential hazards. The specific regulations for the prevention of accidents have to be observed.
- Damages caused by unauthorized modifications carried out on the actuators are excluded from the manufacturer's liability.
- Supply voltage may only be switched on after the proper closure of the main cover or terminal box.

3. Storage

For appropriate storage, the following instructions have to be met:

- Only store the actuators in ventilated, dry rooms.
- Store the actuators on shelves, wooden boards, etc., to protect them from floor moisture.
- Cover the actuators with plastic foil to protect them from dust and dirt.
- Protect the actuators against mechanical damage.

4. Operating conditions

- PS-AMS PSL actuators may be operated at ambient temperatures from -20°C to +60°C.
- Operating modes correspond to DIN EN 60034-1: S2 for short cycle and S4 for standard operation (for actuator specific data see the actuator specific data sheets).
- For protection against moisture and dust, the enclosure rating is IP65 or IP67 according to EN 60529.
- When installing the actuators, leave enough space to allow cover removal (Fig.1).

PS-AMS PSL202-204

PS-AMS PSL208-210
(Stroke 50)PS-AMS PSL208-214
(Stroke 65)

PS-AMS PSL320-325




Figure 1: Installation dimensions

4.1 Installation position




Figure 2: Installation positions

Outdoor usage:



When using the actuators in environments with high temperature fluctuations or high humidity, we recommend using a heating resistor as well as a higher enclosure rating (optional accessories).

5. Function


The PS-AMS PSL actuators are designed as electric valve actuators. The valve is mounted onto the actuator via pedestals. Depending on the type of valve used, mounting pedestals or a special valve mounting plate is required.

Mechanical power is created by a 24 volts DC-motor which is controlled from the electronics via pulse width modulation (PWM). The motor torque is transmitted via a multi-step spur gear to a trapezoidal thread spindle. The spindle itself converts the induced torque into an axial force via a spindle nut. The spindle nut's resulting linear vertical motion is self-locking and is transmitted via a coupling piece to the valve stem.

During power failure and adjustment work the actuators can be emergency-operated via the handwheel (see chapter 6/Manual operation), except when using the fail-safe unit PSCP.

6. Manual operation

The actuators are supplied with a loosely enclosed handwheel in order to operate the actuator in case of power loss or during installation work such as mounting onto a valve or setting the limit positions. Mount the handwheel according to *Figure 3*.



Do not exceed the adjusted electrical stroke limits by handwheel.

The mechanical limits must be set accordingly.


If these instructions are not observed, it may result in malfunction or damage to the actuator.




Operate the handwheel only manually. Do not replace it and do not operate it by using excessive force or a motor. If these instructions are not observed, it may result in malfunction or damage to the actuator.

- The handwheel is permanently engaged and turns during motor operation of the device series PS-AMS PSL202-214.
- The actuators PS-AMS PSL320-325 have a handwheel which has to be engaged for manual operation. The button on the cover has to be depressed to engage the handwheel.


PS-AMS PSL202-204



**PS-AMS PSL208-210
(Stroke 50)**



**PS-AMS PSL208-214
(Stroke 65)***



PS-AMS PSL320-325




Figure 4: Manual operation

**PS-AMS PSL208-214 Stroke 65m: Please remove the handwheel cover*




7. Valve mounting







7.1 PS-AMS PSL202-214

Note: The pictures below show the mounting of a PS-AMS PSL204. The steps are identical for all types.



When mounting the actuator onto the valve, use the handwheel and do not drive the actuator electrically. If these instructions are not observed, it may result in personal injury or damage to the actuator and/or valve.





Before the fastening nuts are tightened, make sure that the pedestal ends are completely inserted into the bores of the valve mounting plate. If necessary, correct the position of the actuator by using the handwheel. If these instructions are not observed, it may result in personal injury or damage to the actuator and/or valve.

7.2 PS-AMS PSL320-325



When mounting an actuator onto a valve, never drive the actuator electrically but use the handwheel.

If these instructions are not observed, it may result in personal injury or damage to the actuator and/or valve.




Figure 5: Mounting the actuator onto the valve

1	=	spindle nut
2	=	grub screw
3	=	coupling piece
4	=	counter nut
5	=	locking nut
6	=	mounting bracket
7	=	pillar nut
8	=	disc springs
9	=	valve stem





Figure 5.1

The valve must be suitably equipped to take the pillars. Please see the individual dimension sheets for the actuator dimensions. Observe the following steps when mounting the actuator:

- Unscrew the locking nut (item 5) from the spindle nut (item 1) and slide it over the valve stem (item 9).
- See if the bore of the coupling piece (item 3) fits the valve stem. If necessary, rebores and/or recut the thread.
- Slide or screw the coupling piece onto the valve stem and bore or pin to the valve stem. You may also secure the coupling piece by using a counter nut (item 4) (Lay the cup springs according to Figure 6 on page 10).
- Slide the pillars into the bore holes of the mounting bracket (item 6) and tighten with the pillar nuts (item 7).
- Extend the spindle nut by hand and move it completely over the disc springs and coupling piece, apply the locking nut and screw it in slightly, extend the spindle nut further and compress the disc springs until the locking nut can be tightened with the supplied face wrench to the stop, the locking nut is then flush with the lower edge of the spindle nut and does not protrude (Figure 5.1), if necessary compress the disc springs further by hand wheel.
- Tighten grub screw (pos. 2) with hexagon socket, locking nut is thus secured against loosening.



Before the fastening nuts are tightened, make sure that the pedestal ends are completely inserted into the bores of the valve mounting plate. If necessary, correct the position of the actuator using the handwheel. If these instructions are not observed, it may result in damage to the actuator and/or valve.



WRONG

CORRECT

7.3 Force/Stroke-Dependent Limit Switch Cut-Off




Figure 6: Standard disc spring coupling

The different methods of arranging the discs are dependent on the type of valve. Three different methods are possible:

- A: Arrangement for a through-valve with "Valve stem retracting" as direction of closing (*Figure 6*).
- B: Arrangement for a 3-way valve (*Figure 6*).
- C: Arrangement for a through valve with "Valve stem extending" as direction of closing (*Figure 6*).



3-way valves using the spring disc arrangement "B" require only half of the spring stroke designated in the spring pressure graph below!

Basic rule:

- For a through-valve, first set the CLOSED position force/stroke-dependent, then the OPEN position stroke-dependent.
- For a 3-way valve set both limit positions force/stroke-dependent.

8. Removing the cover

Please observe the label on the cover of the actuator.



Attention! Observe precautions for handling.

- Ground the actuator.
- Before opening the cover, touch grounded housing parts.



Figure 7: Removing the cover

PS-AMS PSL202 – PS-AMS PSL210 (IP65)

Remove the handwheel by loosening it.
Pull the cover upwards.



For electrical connection the cover don't need to be removed.

PS-AMS PSL214 and PS-AMS PSL202-210 IP67

Remove the handwheel by loosening the grub screw.
Remove the fastening screws of the actuator cover.
Pull the cover upwards.



For electrical connection the cover don't need to be removed.

PS-AMS PSL320 – PS-AMS PSL325

Remove the fastening screws of the actuator cover.
Pull the cover upwards.

9. Electric Supply

9.1 Safety



Electrical connection work may only be carried out by an authorised professional.

When performing electric work on this unit, the local accident prevention regulations must be followed. Observe EN 60204-1 (VDE 0113 part 1) to ensure human safety, integrity of the assets as well as the proper functioning of the unit.

Electric supply lines must be dimensioned for the peak current of the unit and comply with IEC 227 and IEC 245. See relevant data sheet.

Yellow-and-green coded cords may only be used for connection to protective earth.


When leading wires through the cable glands on the actuator, their minimum bending radius has to be considered.



The electric actuators PS-AMS PSL are not fitted with an internal electric isolator, hence a switching device or circuit breaker must be integrated in the facility. It should be installed close to the actuator and should be easy to access for the user. It is important to mark the circuit breaker as this actuator's isolator.



Electric installation as well as over-current and overvoltage protection devices must be conform to the standard DIN IEC 60364-4-41, protective class I resp. protection class 3 (24VAC/24VDC) and also to the standard DIN IEC 60364-4-44 according to the applied overvoltage category of the actuator.



Please protect all of the power supply and control cables in front of the terminals mechanically by using suitable measures against unintentional loosening. Never install the power supply and the control cables together in one line but instead please always use two different lines.








PE earth connection has to be connected to gear casing at  !

Ensure that all connecting cables are stripped to the correct length so that they are protected against electric shock.

9.2 Wiring diagram

Depending on the actuator size, electric terminals are either provided in a terminal box at the actuator or under the cover. After wiring is completed, close the cover of the terminal box and the actuator properly and tighten the cable glands to ensure enclosure as per the specified rating. The wiring diagram might differ for special actuator versions.

																					1-Phasen Wechselspannung / DC 1-Phase AC / DC				3-Phasen 3-Phase AC																
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23				RJ-45 TTL	Taster Button	L1	L2	L3	PE										
↕	↕	↕	↕	↕	↕	↕↕	↕↕	↕	↕	↕	↕	↕	↕	↕	↕	↕	↕↕	↕↕	↕↕	↕↕	↕↕	↕	↕	 	(Option)			↕	↕	↕	 										
+ 0(2) - 10 V			+ 0(4) - 20 mA			max. Last / max. Load 100 mA bei / at 24 VDC		L / + AUF / OPEN				N / - (24V AC/DC - 230VAC)		21 - 40 VDC / 100 mA		+ 0(2) - 10 V		+ 0(4) - 20 mA		GND		(Option)		(Option)		L / + (siehe Typenschild/ see tag plate)		N / - (siehe Typenschild/ see tag plate)		PE		(Option)		RJ-45 TTL		Taster Button					
Sollwert- Eingang			Aktive Positions- rückmeldung			Störmeldung potentialfrei		Binäre Ansteuerung				Netz- ausfall- signal		Ver- sor- gung		Istwert		Zu / Closed		Auf / Open		Wegschalter potentialfreier Kontakt		Versorgungs- spannung		Feldbus- Anschluß		PC Kommuni- kation		Inbetrieb- nahme		Versorgungs- spannung		Power supply voltage		Fieldbus interface		PC commu- nication		Com- mission- ing	
Set value input			Active position feedback			Monitor relay potential-free		Binary input signals				Fail safe signal		Supply		Actual value						Position switch potential-free contact				Power supply voltage		Fieldbus interface		PC commu- nication		Com- mission- ing									
Galvanisch getrennt / Galvanically isolated 1 kV													Process-Sensor										8013770 - S-217_G																		

Schaltnetzteil			
----------------	--	--	--

Figure 8: Electric terminals

9.3 Mains supply


9.3.1 Mains supply 1-phase AC/DC




Electrical connection work may only be carried out by an authorised professional.

Isolate the power supply. **Safeguard the line against unauthorized and unintended restarting.**

Open the terminal box.




The terminal box provides terminals to accommodate rigid and flexible cables of wire widths of 0.14 mm² to 2.5 mm² as well as a PE screw on the housing.



Caution: Please observe the supply voltage and the maximum power consumption of the actuator as indicated on the actuator's tag plate!

Connect supply and control lines to terminals (as indicated in the wiring diagram).

9.3.2 Mains supply 3-phase AC (optional)




Isolate the power supply.

Safeguard the line against unauthorized and unintended restarting.

To connect supply, connect directly to internal mains adapter.

Connect supply and control lines to terminals (as indicated in the wiring diagram for 3-phase AC).



9.3.3 Mains supply PS-AMS PSL320/325 with integrated local control PSC.2



Isolate the power supply.

Safeguard the line against unauthorized and unintended restarting.




Figure 9: Opening the cover

Open the cover of the local control PSC.2.





Figure 10: Connecting mains

Feed the cable through the cable glands in the inner room of the cover. For wiring, loosen the four holding screws of the respective terminal box of the frame. The wiring must be made on the back side of the box.

The terminal box provides terminals to accommodate rigid and flexible cables of wire widths of 0.14 mm² to 2.5 mm² as well as a PE screw on the housing.

			Pin-Number						
Set Value Input	+ 0(2) - 10 V		➔	1	9	➔	21 - 40 VDC / 100 mA	Supply	Process Sensor
	+ 0(4) - 20 mA		➔	2	10	➡	+ 0(2) - 10 V	Actual Value	
	GND		➔	3	11	➡	+ 0(4) - 20 mA		
Active Feedback	+ 0(2) - 10 V		➡	4	12	➡	GND		
	+ 0(4) - 20 mA		➡	5	13	(reserved)			
	GND		➡	6	14	(reserved)			
(reserved)				7	15	(reserved)			
(reserved)				8	16	(reserved)			




			Pin-Number						
Binary Input Signals	<input type="checkbox"/>	115V / 230V AC	L/+ OPEN	➔	17	25	➡	L/+ (24V AC/DC)	Fail Safe Signal
	<input type="checkbox"/>	24V AC/DC	N/-	➔	18	26	➡	N/- (24V AC/DC)	
		L/+ CLOSE	➔	19	27	↔	(Option)	Closed NC	
Monitor Relay potential-free	max. load 100 mA at 24 VDC		↔	20	28	↔	(Option)	Closed	Position Switch potential-free contact
			↔	21	29	↔	(Option)	Open NC	
Position Switch potential-free contact	Closed NO	(Option)	↔	22	30	↔	(Option)	Open	Power Supply Voltage
	Open NO	(Option)	↔	23	31	➡	N/- (see name plate)		
PE			➔		32	➡	L/+ (see name plate)		


S-224_C

Figure 11: Electric terminals PS-AMS PSL320/325 with local control PSC.2 with 1-phase AC/DC

Connect supply and control lines to terminals.

			Pin-Number						
Set Value Input	+ 0(2) - 10 V →		1	9	→	21 - 40 VDC / 100 mA	Supply	Actual Value	Process Sensor
	+ 0(4) - 20 mA →		2	10	←	+ 0(2) - 10 V			
	GND →		3	11	←	+ 0(4) - 20 mA			
Active Feedback	+ 0(2) - 10 V ←		4	12	←	GND			
	+ 0(4) - 20 mA ←		5	13	(reserved)				
	GND ←		6	14	(reserved)				
(reserved)			7	15	(reserved)				
(reserved)			8	16	(reserved)				

			Pin-Number						
Binary Input Signals	24V AC/DC - 230 VAC	L/+ OPEN →	17	25	←	L/+ (24V AC/DC)	Fail Safe Signal		Position Switch potential-free contact
		N/- →	18	26	←	N/- (24V AC/DC)			
		L/+ CLOSE →	19	27	↔	(Option)	COM		
Fault Indication Relay potential-free	max. load 100 mA at 24 VDC	↔	20	28	↔	(Option)	NC/NO*		
		↔	21	29	↔	(Option)	COM		
Power Supply Voltage	L2 400 VAC →	22	30	↔	(Option)	NC/NO*	Power Supply Voltage		
	L3 400 VAC →	23	31	←	N				
			24	32	←	L1 400 VAC			

PE 

S-310_B


*) Position-Switch NC / NO: swap at terminal X8 to change

Figure 12: Electric terminals PS-AMS PSL320/325 with local control PSC.2 with 3-phase AC

9.4 Interfaces

The actuator PS-AMS PSL has several interfaces inside the terminal box which can be configured by the parameterizing software PSCS or by the local control PSC.2 (see relevant manuals).


9.4.1 Communication interface



For communication and parameterization with a PC or a hand-held device, connect the communication cable to the RJ45-connector. Actuator parameters can be set using the software PSCS (see relevant manuals).


9.4.2 Input terminals

9.4.2.1 Galvanically isolated set-value



Terminals 1 to 3 are used to receive a parameterisable modulating set-value for control operation within the range of 0-20 mA or 0-10 V. Split range is also possible.

9.4.2.2 Sensor feedback for process controller (optional)




Terminals 15 to 17 are used to receive a process sensor's feedback to the - optional - process controller, in the parameterisable range of 0-20 mA or 0-10 V.



Caution!


The following binary inputs (9.4.2.3 und 9.4.2.4) have priority over the modulating set-value. If the actuator is parameterised for modulating service, these set-value settings are disregarded in the case a binary signal is applied. Only after disconnection of the binary signal the actuator will reposition according to the set-value applied.

9.4.2.3 Galvanically isolated binary input



Terminals 9 to 11 are for binary open/close signals. Standard voltage level is 24 V, option is for 115/230 V; see wiring plan. The actuator is then driven in 3-point service.


9.4.2.4 Fail-safe port for binary input (optional)



The fail-safe port (terminals 12 and 13) allows driving the actuator to a parameterized safety position by applying a voltage of 24 V. This input has priority over the galvanically isolated binary input.


9.4.3 Output terminals

9.4.3.1 Active position feedback




Terminals 4 to 6 are giving active position feedback, parameterisable within the range of 0-20 mA or 0-10 V.

9.4.3.2 Additional position switches (optional)




The activation points of the optionally available position switches are freely adjustable via cams. Terminals 18/19 and 20/21 provide potential-free opening or closing contacts. The standard switches are rated to 230 VAC/10 A (6 A inductively). Special switches with gold plated contacts are available for low power (up to 100 mA and 30 V).

9.4.3.3 Voltage feed to process sensor (optional)



Terminals 14 and 17 provide an unregulated output voltage of 21 to 40 VAC at maximum 100 mA to feed an external process sensor.

9.4.3.4 Fault indicating relay



This potential-free normally-closed relay contact (terminals 7 and 8) allows displaying parameterisable fault indication to the control room. For configuration use the communication software PSCS.

9.4.3.5 Fieldbus interface (optional)


Optionally a fieldbus interface can be fitted to the PS-AMS actuator, with wiring to a terminal block or an external socket.

-> See special operating manual for PS-AMS fieldbus.

9.5 Accessories

9.5.1 Heating resistor (optional)

Actuators PS-AMS PSL can be fitted with a heating resistor. When using actuators in environments with high temperature fluctuations or high humidity, we suggest a heating resistor to be fitted to prevent the build-up of condensation within the enclosure.



In actuators PS-AMS PSL the heating resistor is powered via the power supply of the actuator, so it does not have to be fed separately. For retrofitting the heating resistor, wiring of the two cables has to be made to the terminals on the main board as per the figure on the left.

The heating resistor is available in two different versions (for 24 VAC/DC or 115-230 VAC). Please choose acc. to the voltage supply of the actuator.

Figure 13: Wiring of the heating resistor




Figure 14: Mounting of the heating resistor

Mounting of the heating resistor has to be made to the indicated place on the base plate by using the screws provided. Route the cables in a way to prevent them from being squashed by the main cover, and from being touched by moving parts inside the actuator.

9.5.2 Adjusting additional position switches (optional)

In PS-AMS PSL two switches for position feedback are available as factory-mounted option. They are potential-free changeover contacts. They are available with silver contacts (for currents between 10 mA and 5 A at maximum 230 V) or with gold-plated contacts (for currents between 0,1 mA and 30 mA at maximum 30 V). Connection goes to terminals 18/19 and 20/21 (see chapter 9.2).




Figure 15: Adjusting of the cams

The cams for closing the switches are located on the switch plate, and are adjustable with a small screwdriver. Cam 1 is for retracting the spindle nut, while cam 2 is for extending the spindle nut out of the actuator.



The potentiometer must not be adjusted. Non-observance may cause damage to the actuator!

10. Status display / Commissioning elements




Figure 16: Status display

A red and a green LED on top of each other inside the terminal box indicate the status of the actuator.

Another single red LED (optional) signals the status of the optional fieldbus interface. -> See special operating manual for PS AMS fieldbus.

The commissioning button for starting the automatic commissioning run (to adjust the actuator to the valve) is located inside the terminal box, below the communication port.

11. Closing the cover

PS-AMS PSL201 – PS-AMS PSL210 (IP65)

Please observe the label on the cover of the actuator.

PS-AMS PSL202 – PS-AMS PSL210 (IP67) and PS-AMS PSL214

- Put the cover on the actuator and ensure that the two fixing screws are positioned over the corresponding threaded holes.
- Slightly tighten down the fixing screws with an Allen key. If the screws don't lock, move the cover slightly.
- Push the cover downwards and ensure that it slips over the sealing ring of the actuator.
- Tighten the screws.

PS-AMS PSL320 – PS-AMS PSL325




Figure 17: Closing the cover

- Check that the sealing ring on the periphery of the housing sits correctly in the groove.
- Put the cover on the actuator and ensure that the 3 fixing screws are positioned over the corresponding threaded holes and that the button is positioned over the release pin of the actuator housing.
- Tighten down the fixing screws with a corresponding screwdriver.

12. Operation

All internal parameters, like required motor torque, actual position, functional status, etc., are being permanently monitored during operation of the actuator PS-AMS PSL. This ensures that the actuator positions with optimum accuracy, and closes the valve always tightly. Deviations can be read out via communication software PSCS or via local control PSC.2 (see respective instruction manuals), or can be displayed to the control room using the fault indication relay. This provides maximum safety of the process.

12.1 Cut-off in end positions

Cut-offs of the PS-AMS PSL actuators can be adjusted to meet the valve function in an optimum way by using the communication software PSCS (using a special interface cable, or optionally bluetooth connection). This will result in different behavior of the actuator. In case a position is surpassed or not reached, this can be read out via the fault indication relay or via the communication software PSCS.

12.1.1 Cut-off by force/torque

The actuator delivers the programmed maximum force/torque each time when driving to this end position. If the closing point inside the valve dislocates, e.g. when a seat gasket wears, then the actuator will drive further in its possible actuation range to try to reach the programmed force/torque.

12.1.2 Cut-off by position automatically

In normal operation, the actuator will stop at the position which was found at a mechanical stop in the valve or the actuator during automatic commissioning. If the closing point inside the valve dislocates, the actuator will NOT follow this dislocation but it will always stop at the point initially found.

12.1.3 Cut-off by position

In normal operation, the actuator will stop at the point which was defined by manual commissioning. This position is not depending on any mechanical stop inside the valve or actuator.

13. Commissioning



The electrical connection and commissioning with mains voltage applied may only be carried out by trained specialist personnel!
Do not touch any connection lines during commissioning!

The actuator is shipped in the „not commissioned“ condition with the green LED flashing slowly. There will be **no** response to any input (set value or open/close signal). To make the actuator operational, it has to be commissioned to a valve.

Depending on the type of cut-offs programmed (see 12.1) there are two ways to do commissioning:

- **Automatic** commissioning is done if at least one of the cut-offs is set to be “by force/torque” or “by position automatically”.
- **Manual** commissioning has to be made in case both cut-offs are “by position”, either via software PSCS or via control box PSC.2.



Caution!

Electrical operation of the actuator is allowed only after mounting to a valve!




Attention! Observe precautions for handling. Electrostatic sensitive devices.

13.1 Automatic commissioning


(Only available if at least one of the cut-offs is set to be “by force/torque” or “by position automatically”).

①




Press the commissioning button for 3 sec
(For position of commissioning button please see Figure 16).

②



Commissioning in progress (Green LED is flashing, actuator drives in both positions).


③



Green LED lights – Actuator successfully commissioned and ready to be used.


13.2 Manual commissioning

①




Connect your PSCS-USB cable with your PC and start the software.

②



Select actuator type and interface in the software.

③




Select Operate -> Commissioning and confirm the dialog with OK.

④


When doing manual commissioning, make sure that the correct set value for the closed position, or the binary signal for driving to closed position is permanently applied, depending on the parameterised mode of operation.

⑤



Adjust the closed position and check it with „send“; Save with OK.

⑥



Green LED lights – Actuator successfully commissioned and ready to be used.

Note

If the parameterized valve stroke, starting from the adjusted closed position, exceeds the possible actuator stroke, then the operating stroke will be reduced to the resulting maximum possible value.

14. Status messages

14.1 Fault indicator relay

Fault messages can be transmitted to the control room with a maximum load of 24 VDC/100 mA via a closing contact at terminals 7 and 8. The messages can be parameterized via software PSCS.

The contact on terminals 7 and 8 is closed when there is no fault and the drive is supplied with power.

-> See relevant manuals PS-AMS PSCS

14.2 Tracing faults

See the table on page 24 for explanation of the blinking codes of the status-LEDs.

15. Maintenance

Under the conditions of use as per specification as lined out in the data sheet, the PS-AMS PSL actuators are free of maintenance. All gears are lubricated for their service life and do not require to be re-lubricated. Clean the actuators with a dry soft cloth and do not use any cleaning agent. Do not use any coarse or abrasive materials.



Caution !

During maintenance and repair the actuator must not be operated electrically.

16. Disposal



According to 2012/19/EU on waste electrical and electronic equipment (WEEE), the devices described here must not be disposed of via municipal waste disposal companies.

If you are unable or unwilling to arrange for disposal by a specialist company, you may return the equipment to the manufacturer, who will then ensure that the equipment is disposed of properly for a flat fee.

17. Safety on transportation

For transportation and storage all cable glands and connection flanges have to be closed to prevent ingress of moisture and dirt. A suitable method of packaging is required for transporting to avoid damage of coating and any external parts of the actuator.

18. Accessoires

Various options are available in order to adapt the actuators to the various service conditions. A list of accessories for each actuator type is shown on the actuator data sheet.

Accessories/Options	Position Signal Switches	2WE	Potential-free additional position switches with silver contacts (0.1 A - 5 A switching current)
	Position Signal Switches Gold	2WE Gold	Potential-free additional position switches with gold contacts (0.1 mA - 100 mA switching current)
	Binary Inputs 115-230VAC*		Binary input voltage of 115-230 VAC for ON/OFF control
	Fail-Safe*	PSCP	Emergency power supply based on supercapacitors, safety position OPEN, CLOSED or free defined position
	Fieldbus Interface*		Digital transmission of nominal and actual value per mill or percent, report of monitoring and diagnostic data using Profibus DP (PSPDP) or CANOpen (PSCA) interfaces, additional interfaces available on request
	Local Control*	PSC.2	Illuminated display to show the actuator status and lockable selector to switch between modes: automatic, manual process ON/OFF, STOP and parameter menu. Control buttons for manual movement, menu operation and adjustment of parameters, display of diagnostic information
	Remote Local Control		Mounting separately from the actuator (incl. 10 m connection cable)
	Data Cable	PSCS-USB	USB data cable enables the communication between the actuator and a PC by using the software PSCS
	Fail-Safe Port*	FSP	Signal port to drive to a "safety position", selectable fail-safe position, standard 24 V
	IP67		Increased enclosure IP67
	Heating Resistor	HR	Heating resistor to prevent condensation

*not retrofittable, except: PS-AMS PSL202-214

19. Tracing faults

Red LED			Green LED					
Glowing permanently	Flashing quickly	Flashing slowly	Off	Glowing permanently	Flashing quickly	Flashing slowly	Off	

Red LED				Green LED				
Glowing permanently	Flashing quickly	Flashing slowly	Off	Glowing permanently	Flashing quickly	Flashing slowly	Off	
								Faults within the actuator's environment
		x				x		Actuator drives into a preset position
		x					x	Set-value disconnected or outside the parameterized range
	x			x				Stored end position could not be reached
	x				x			Stored end position has been passed over
	x					x		Actuator supply voltage too low
								Faults within the actuator
x				x				Actuator has reached lifetime limit
x					x			Faulty electronics or invalid parameters
x						x		Critical or maximum temperature reached
x							x	Mechanical fault in the actuator
								Probable reasons
								Possible remedy
								1) Signal is applied to the binary fail-safe input 2) Supply voltage failure on actuators with optional PSCP
								1) Set-value not connected 2) Wrong polarity of set-value 3) set-value signal outside parameter range, please check
								1) Disconnect the signal 2) Check supply voltage
								1) Apply set-value 2) Check the set-value polarity 3) Check the set-value range
								Loose or dirty valve seat
								Valve seat worn or defective
								1) Check mains wiring 2) Check supply voltage -> see datasheet 3) Contact PS service team
								Wear and/ or running time
								1) Supply voltage interrupted during commissioning 2) Defective electronic component
								1) Reload parameters (-> see manual PS-AMS PSCS), then repeat commissioning 2) Contact PS service team
								1) Too high numbers of starts 2) Ambient temperature too high
								1) Check application and its adjustment 2) Check ambient temperature and try to reduce it -> see relevant data sheet
								Defective mechanical part
								Contact PS service team

20. EC Declaration of Conformity

Declaration of Incorporation of Part Completed Machinery and EC Declaration of Conformity in compliance with the Directives on EMC and Low Voltage

We,

PS Automation GmbH
Philipp-Krämer-Ring 13
D-67098 Bad Dürkheim

Declare under our sole responsibility that we manufacture electric actuator series

PSR-E...; PSQx03...; PSQ-E...; PSQ-AMS...; PSL-Mod.4...;
PSL-AMS...; PSF...; PSF-M...; PSF-Q...; PSF-Q-M...

according the requirements of the

EC Directive 2006/42/EC

as part completed machinery. These actuators are designed to be installed on industrial valves.
It is prohibited to take the actuator into service until it has been ensured that the complete machine conforms
the applicable machinery directives.
The technical documentation described in Annex VII, part B has been prepared.

The above actuators further comply with the requirements of the following directives.

2014/30/EU	Electromagnetic Compatibility (EMC)
2014/35/EU	Low Voltage (LVD)
2011/65/EU + 2015/863/EU	Restriction of Hazardous Substances (RoHS)

furthermore, the following harmonised standards have been applied:

EN 61000-6-2: 2005	Electromagnetic compatibility (EMC), Generic standards- Immunity for industrial environments
EN 61000-6-3: 2007	Electromagnetic compatibility (EMC), Generic standards- Emission standard for residential, commercial and light-industrial environments
EN 61010-1: 2020	Safety Requirements for Electrical Equipment for Measurement, Control and Laboratory use

Bad Dürkheim, 2022



Christian Schmidhuber
(General Manager)

CAUTION!

To ensure compliance of these actuators with the above directives, it is the responsibility of the specifier, purchaser,
installer and user to observe the relevant specifications and limitations when taking the product into service. Details are
available on request, and are mentioned in the Installation and Maintenance Instructions.

21. CA Declaration of Conformity

Declaration of Incorporation of Part Completed Machinery and CA Declaration of Conformity in compliance with the Legislation on EMC and Low Voltage

We,

**PS Automation GmbH
Philipp-Krämer-Ring 13
D-67098 Bad Dürkheim**

Declare under our sole responsibility that we manufacture electric actuator series

PSR-E...; PSQx03...; PSQ-E...; PSQ-AMS...; PSL-Mod.4...; PSL-AMS...; PSF...; PSF-M...

according the requirements of the

2008 No. 1597

Supply of machinery (safety) regulations

as part completed machinery. These actuators are designed to be installed on industrial valves.
It is prohibited to take the actuator into service until it has been ensured that the complete machine conforms
the applicable machinery legislation.
The technical documentation described in Annex VII, part B has been prepared.

The above actuators further comply with the requirements of the following legislations:

**UK SI 2016 No. 1091 and
Amendments**

The Electromagnetic Compatibility Regulations 2016

**UK SI 2016 No. 1101 and
Amendments**

The Electrical Equipment (Safety) Regulations 2016

**UK SI 2012 No. 3032 and
Amendments**

**The Restriction of the Use of Certain Hazardous Substances in
Electrical and Electronic Equipment Regulations 2012**

the provisions of the legislations and their compliance are given by the following named standard(s), which
have been applied:

EN 61000-6-2: 2005

Electromagnetic compatibility (EMC), Generic standards-
Immunity for industrial environments


EN 61000-6-3: 2007

Electromagnetic compatibility (EMC), Generic standards-
Emission standard for residential, commercial
and light-industrial environments

EN 61010-1: 2020

Safety Requirements for Electrical Equipment for
Measurement, Control and Laboratory use

Bad Dürkheim, 2021


Christian Schmidhuber
(General Manager)

CAUTION!

To ensure compliance of these actuators with the above directives, it is the responsibility of the specifier, purchaser,
installer and user to observe the relevant specifications and limitations when taking the product into service. Details are
available on request, and are mentioned in the Installation and Maintenance Instructions.

Our representatives:

Italy

PS Automazione S.r.l.
Via Pennella, 94
I-38057 Pergine Valsugana (TN)
Phone: <+39> 04 61-53 43 67
Fax: <+39> 04 61-50 48 62
E-mail: info@ps-automazione.it

India

PS Automation India Pvt. Ltd.
Srv. No. 25/1, Narhe Industrial Area,
A.P. Narhegaon, Tal. Haveli, Dist.
IND-411041 Pune
Phone: <+ 91> 20 25 47 39 66
Fax: <+ 91> 20 25 47 39 66
E-mail: sales@ps-automation.in

To find out more about all our sales partners and subsidiaries please scan the QR code below or visit our website: <https://www.ps-automation.com/ps-automation/locations/?lang=en>



PS Automation GmbH

Philipp-Krämer-Ring 13
D-67098 Bad Dürkheim

Phone: +49 (0) 6322 94980 – 0
E-mail: info@ps-automation.com
www.ps-automation.com

