

Potentiometer for position feedback

Potentiometer kit for PSQ, PSR and PSL Mod.3



Scope of delivery


Potentiometer

Pinion*

Cable

Nut and washer

Potentiometer kit for PSL Mod.4



Scope of delivery

Pinion*

Cable

Mounting kit (potentiometer bracket, spring plate, screws, nut, washer)

* **Attention:** The potentiometer kits differ by the used pinion, which is dependent of stroke respectively rotation angel of the actuator. Please specify the required stroke respectively the rotation angel of your application!

Required potentiometer	PD210	PD2 210	PD210 100Ω, 200Ω, 500Ω, or 2kΩ	Options
Used accessory/ option	1 x 1kΩ	2 x 1kΩ		
Position Transmitter PSPT02 or PSPT03	x			
Positioner PSAP.2A	x			
Positioner PSAP.3	x			
Position feedback (connection terminal)	x		x	
Position feedback (connection terminal) and using PSAP or PSPT at the same time		x		
Using PSPT and PSAP.2A at the same time		x		